


## Double Sided Top-of-Wall


**1**

Drill top of brick or block wall with 28mm core bit to a depth of 200 - 300mm to suit metal fixing stud.



**2**

Apply two part resin chemical fixing into hole.




**3**

Fit double sided top of wall post with metal fixing stud into hole.


**Posts are available at:**

300mm high  
600mm high  
900mm high  
1200mm high

The metal stud can be cut to size to suite the depth of hole drilled.



## Double Sided Top-of-Wall





**4**

Position of post centres to be equal to the width of the fence panel to be installed.

When at the end of a fence run the panel should end on the outer edge of a post.

**5**


Attaching the first panel side to the double sided post.



**6**

Intermediate panels are fixed midway to the front of the post. For end of a fence run the panel should be fixed on the outer edge of a post.

## Double Sided Top-of-Wall



**7**


Attaching the second panel side to the double sided post.

The second panel is fixed against the first panel encapsulating the post.

Use 30mm stainless steel screws every four battens.

**8**


The completed panel



**9**

The Capping Rail is pushed down onto the profiled post top and back batten up stand.

3off 63mm cedar coloured powder coated stainless steel screws should be used to fix the capping rail into position.







## Double Sided Top-of-Wall

**10**

Completed double sided top-of-wall panel.



Sample panels showing square edge cedar slats, bevel edge slats also available.

Both types available with or without hit & miss arrangement.

Top-of-wall post fixings shown with metal stud or foot plate options.