


Slattered Fencing



1


Cequence Cedar posts to be set out with centres equal to the width of the fence panel to be installed.

When at the end of a fence run the panel should end on the outer edge of a post.

2

Install Cequence Cedar posts into ground


For more information on Post Saver Sleeves visit: www.postsaver.com



3

Screw Cequence panels into front face of post.


Intermediate panels are fixed midway to the front of the post. For end of a fence run the panel should be fixed on the outer edge of a post.



Top of back batten upstand to be flush with top of post.

Screw fixings should be every four batten gap.

The bottom of the panel should be at least 20mm off the ground





4

Screws should pass through the gaps between the horizontal battens into the front of the back batten and then into the post.

63mm cedar coloured powder coated stainless steel screws should be used.

5


Aligning panels



6

The Capping Rail is pushed down onto the profiled post top and back batten upstand.

3off 63mm cedar coloured powder coated stainless steel screws should be used to fix the capping rail into position.




7

Attaching the Capping Rail

8

The completed panel front face



9

The completed panel rear view

